

Equipment Technical Bulletin

L5000Plus/XL Data Circuit Board

Warning

PROBLEM

Customers have reported damage to their L5000Plus/XL printed circuit boards (both pump driver and Data PCBs) when attempting to install the Data PCB with the power switch on.

SOLUTION

As with ALL Beta equipment, you must always disconnect power when performing any PCB installation or maintenance.