

# Premium-Pak Detergent

## Encapsulated Dish Machine Detergent

Premium-Pak Detergent is a highly concentrated, heavy duty formula with a low use cost. It removes tough, greasy soils. Premium-Pak Detergent is encapsulated, so it's safe, simple and convenient to use!

### Specifications

<b>Color</b>	White
<b>Scent/Odor</b>	None added
<b>Character</b>	Free flowing powder
<b>Foam</b>	Non-foamer
<b>pH Use Dilution</b>	12.0 - 12.5
<b>Phosphorus Content</b>	7.5%
<b>Approvals</b>	cRc

### Pack Sizes

<b>4447918</b>	4/9 pound case
----------------	----------------



### Directions For Use

**Equipment:** Automatic warewash dispensing system.

**To Load Product:**

Product will be automatically dispensed by the dishmachine dispenser during the machine cycle. To load product into dispenser, remove empty capsule from dispenser. Using tab on top of capsule, remove lip insert to expose cap. **DO NOT UNSCREW THE CAP.** Place the new capsule in the dispenser with the open mouth pointed down.

**To Wash Dishes:**

1. Pre-flush and/or scrape dishes before washing.
2. Rack dishes properly and place racked dishes inside dishmachine.
3. Wash, rinse and sanitize dishes as directed by your representative
4. Remove rack from dishmachine and allow dishes to air dry.

### Product Demo



Scan the QR code with your mobile device to view an instructional video featuring this product!

### Safety Reminder

Read and understand the label and Safety Data Sheet (SDS). These provide a description of hazards, precautions, personal protective equipment, first aid, 24 Hour Emergency lines, storage data and other safe handling information. The SDS is available on our website at [www.uschemical.com](http://www.uschemical.com) and is also available by scanning the QR code on the label.

