Detergent for Institutional Laundry

FEATURES

BENEFITS

- Hyper-concentrated formula
- · Extremely low use rate
- Totally-enclosed-dispensing (TED™)
- Eliminates spill hazard

RECOMMENDED USES

For institutional laundry use ONLY.

SPECIFICATIONS

Color : Dark royal blue **pH use dilution** : 6.00 - 7.00 **Scent** : Citrus **Phosphorus content** : 0.00%

Character : Clear, slightly viscous liquid Approvals : cRc, Ozone, HE

Foam : Moderate to low



IMPORTANT

Read and understand the label and Safety Data Sheet (SDS). These provide a description of hazards, precautions, personal protective equipment, first aid, 24 Hour Emergency lines, storage data and other safe handling information. The SDS is provided with each container shipped. It is also available on our website or from the distributor.

PRODUCT DIRECTIONS

EQUIPMENT TO USE

NEXUS™ Suds is designed to be used only through the exclusive NEXUS Laundry Dispensing System.

DIRECTIONS TO USE

USE DILUTION: Concentration varies due to environmental conditions and load size. Your sanitation specialist will adjust properly to meet your needs. 1. Pre-sort laundry prior to wash. 2. Pre-soak and/or pre-spot laundry when necessary. 3. Place proper amount of soiled fabric into laundry machine. 4. In wash cycle, inject NEXUS Break and NEXUS Suds. 5. When bleaching, inject NEXUS Destainer or NEXUS Oxygen Bleach into laundry machine. When souring and softening, inject NEXUS Sour/Soft or NEXUS Sour and NEXUS Softener. A final pH of 5.5 - 6.5 is recommended for the fabric.

*This product is compatible with ozone laundry systems.

PACKAGING

This product is available in 2/3100 mL canisters. (4284135)



02/15

