

MECHANICAL WAREWASH DETERGENT LP

•

BENEFITS

FEATURES

- High alkaline
- Concentrated
- Excellent water conditioning
- Totally Enclosed Dispensing (TEDTM)

RECOMMENDED USES

For Institutional Use Only. DO NOT USE ON ALUMINUM OR ANY SOFT OR PRECIOUS METALS.

SPECIFICATIONS

Character	:	Red None added/Amine Clear, non-viscous liquid	pH use dilution Phosphorus conter Approvals	nt:	
Foam	:	Non-foamer			

IMPORTANT

Read and understand the label and Safety Data Sheet (SDS). These provide a description of hazards, precautions, personal protective equipment, first aid, 24 Hour Emergency lines, storage data and other safe handling information. The SDS is available on our website at www.uschemical.com and is also available by scanning the QR code on the label.

Removes tough, burned-on soil

Can be used in all water hardness conditions

Efficient and economical

Eliminates spill hazard

PRODUCT DIRECTIONS

EQUIPMENT TO USE

Automatic warewash dispensing system.

DIRECTIONS TO USE

USE DILUTION: Concentration varies due to environmental conditions. Your sanitation specialist will adjust properly to meet your needs. **FOR LOW TEMPERATURE WAREWASHING:** 1. Pre-flush and/or scrape dishes before washing. 2. Rack dishes properly. Place dishes in machine. 3. Wash using this product. 4. In rinse cycle, use a recommended rinse additive. 5. Sanitize using an approved chlorinated sanitizer at 50 ppm. Test using chlorine test papers or a liquid chlorine test kit. 6. Allow dishes to air dry.

FOR HIGH TEMPERATURE WAREWASHING: 1. Pre-flush and/or scrape dishes before washing. 2. Rack dishes properly. Place dishes in machine. 3. Wash using this product. Maintain wash temperature at 150°-160°F. 4. In rinse cycle, use a recommended rinse additive. Maintain rinse temperature at 180°-190°F. 5. Allow dishes to air dry. Do not use on aluminum.

PACKAGING

This product is available in 2/3100 mL cases (5941601).

