

Equipment Technical Bulletin

D3000 Not Delivering Recharge Dose with Door Machine/Timed Mode



OVERVIEW/ISSUE

When D3000 is used on a door machine in potentiometer-timed mode, the detergent pump recharge may not function.

EXPLANATION

This problem occurs if the D3000 PCB was previously programmed or controlled with a Uniview and Menu 2 was set to a "2" for conveyor mode at some point in history. D3000 PCBs or units that are new and whose default programmed values have not changed are not affected by this ETB.

SOLUTION

If you experience this problem you will need to connect a Uniview programmer to your D3000 PCB and reprogram the Menu 23 setting to "1" (Uniview-controlled) then change the Menu 2 setting to "2" ("DOOR"). Finally, go back to Menu 23 and set back to "0" (potentiometer-controlled). This resets the D3000 PCB to work properly.



Beta Technology
2841 Mission Street
Santa Cruz, CA
U.S.A 95060-2142

Customer Service

TEL: 831 • 426 • 0882
TEL: 800 • 858 • 2382 (toll-free in U.S.A.)
FAX: 831 • 423 • 4573
FAX: 800 • 221 • 8416

<http://www.beta-technology.com>

Global Technical Customer Service

North America:
TEL: 800 • 468 • 4893 (toll-free in U.S.A.)
TEL: 262 • 631 • 4461 (international)
Europe, Middle East & Africa:
TEL: +1 630 • 513 • 9799

Asia Pacific:

TEL +1 86 21-50509900 x 2520
Japan:
TEL: +1 090-6506-5140
Latin America
TEL: +1 - 541148428270

Beta Technology is ISO 9001 Certified