



U S Chemical **NEXUS™ OXYGEN BLEACH**

Hydrogen Peroxide Bleach for Institutional Laundry

FEATURES

- Concentrated
- Oxygen based
- Rapid solubility
- Safe on all fabrics
- Totally-enclosed-dispensing (TED™)

BENEFITS

- Low use cost
- Safe on all colors
- Begins destaining quickly
- No extra pre-sorting
- Eliminates spill hazard



RECOMMENDED USES

For institutional laundry use only.

SPECIFICATIONS

Color	: Colorless	pH use dilution	: 5.0-7.0
Scent/Odor	: Pungent (none added)	Phosphorus content	: 0.00%
Character	: Clear, non-viscous liquid	Approvals	: cRc
Foam	: None		

IMPORTANT

Read and understand the label and Safety Data Sheet (SDS). These provide a description of hazards, precautions, personal protective equipment, first aid, 24 Hour Emergency lines, storage data and other safe handling information. The MDS is provided with each container shipped. It is also available on our website or from the distributor.

PRODUCT DIRECTIONS

EQUIPMENT TO USE

NEXUS Oxygen Bleach is designed to be used only through the exclusive NEXUS Laundry Dispensing System.

DIRECTIONS TO USE

NEXUS Oxygen Bleach is part of the NEXUS Laundry Dispensing System and is designed to be used in combination with other NEXUS products as determined by your chemical specialist. **USE DILUTION:** Concentration varies due to environmental conditions and load size. Your sanitation specialist will adjust properly to meet your needs. 1. Pre-sort laundry prior to wash. 2. Pre-soak and/or pre-spot laundry when necessary. 3. Place proper amount of soiled fabric into laundry machine. 4. In wash cycle, inject Nexus Break and Nexus Suds. 5. When bleaching, inject Nexus Oxygen Bleach into the laundry machine. **NOTE:** This product is most effective when used in hot water (150-160 °F). 6. When souring and softening, inject Nexus Sour/Soft or Nexus Sour and Nexus Softener. A final pH of 5.5-6.5 is recommended for the fabric.

PACKAGING

This product is available in 2/3100 mL canisters (5120845).

