

Surpass™

Metal Safe Detergent

Surpass is a chlorinated, metal safe warewash detergent. In normal soil conditions and all water hardness conditions, the use of this product will provide clean, sparkling ware. It is safe for use on aluminum ware.

Specifications

| | |
|---------------------------|-----------------|
| Color | White |
| Scent/Odor | Chlorine odor |
| Character | Granular powder |
| Foam | Non-foamer |
| pH Use Dilution | 11.0 - 12.0 |
| Phosphorus Content | 6.7% |
| Approvals | cRc |

Pack Sizes

| | |
|----------------|----------------|
| 5392381 | 4/8 pound case |
|----------------|----------------|



Directions For Use

Equipment: Recommended warewash dispensing system.

Use Dilution: Varies due to environmental conditions.

DO NOT use in conventional, water-filled (reservoir) systems. Dispenser will NOT activate unless a canister is in unit.

1. Remove the small outer cap with flip tab from canister cap. DO NOT remove the large inner cap.
2. Place the canister into the concentrate dispenser, open end down. Use handle when transporting canister.
3. DO NOT remove concentrate canister until completely empty.
4. To remove empty canister, lift it from the dispenser by the handle and turn upright to avoid spills. Dispose of canister immediately. DO NOT reuse empty canister.

5. Place new concentrate canister into dispenser.

NOTE: Dispenser will not activate unless a canister is in unit.

Product Demo



Scan the QR code with your mobile device to view an instructional video featuring this product!

Safety Reminder

Read and understand the label and Safety Data Sheet (SDS). These provide a description of hazards, precautions, personal protective equipment, first aid, 24 Hour Emergency lines, storage data and other safe handling information. The SDS is available on our website at www.uschemical.com and is also available by scanning the QR code on the label.

